



































































T3K80/2E - R.5,4



		Code	Description	Qty
1		205153A/A	Gear box	1
2		3VP016	Stud bolt	6
3		3DEA012Z	Nut	6
4		3VTE027	Screw	2
5		3RE012	Washer	2
6		213820P	Breather plug	1
7		205131G	PTO shaft	1
8		205142G	Gear	1
9		205132N	Spacer	1

10		3CU009	Ball bearing	1
11		3CU134	Ball bearing	1
12		205129A/A	Cover	1
13		3OR004	O-Ring	1
14		205127A/A	Cover	1
15		205148F	Gasket	1
16		3AT010	Seal ring	1
17		3VTE002	Screw	3
18		205154B	Cover	1
19		205147F	Gasket	1
20		3VTE001	Screw	8
21		204470B	Magnetic plug	1
22		205441G	Shaft with pinion	1
23		3LI011	Key	2
24		3CU020	Ball bearing	1
25		3CU021	Ball bearing	1
26		205128A/A	Cover	1
27		3AT006	Seal ring	1
28		3OR004	O-Ring	1
29		3AFI008	Seeger	1
30		3AP003	Seal ring	1
31		205149F	Gasket	1
32		205438A	Pump support	1
33		205202F	Gasket	1
34		205200A/A	Pump body	1
35		3VP005T	Stud bolt	2
36		3DEA010T	Nut	2
37		3VP016	Stud bolt	4
38		3DEA012Z	Nut	4
39		3VP022	Tie rod	8
40		3DEA012Z	Nut	6
41		203990A	Wear ring	1
42		3NO019	Plug	2
43		205640F	Stuffing-box ring	6
44		201007C	Stuffing-box flange	1
45		203951A00	Impeller	1
46		203986T	Spacer	1
47		203947A/A	Diffuser	1
48		203990A	Wear ring	2
49		203950A00	Impeller	1
50		217274N	Self-locking nut	1
51		203952A	Diffuser shell	1
52		3NO019	Plug	1
53		3OR069	O-Ring	1
54		203953A/1A	Suction cover	1
55		203990A	Wear ring	1
56		218271F	Gasket	1
57		201691C	Bush	1
58		205505N	Foot	1
59		204477P	Universal joint guard	1
60		212497I	Washer	1
61		206715D	Washer	1
62		3DEB012	Nut	2
63		3RB008Z	Washer	3
65		205464F	Gasket	1
66		3RB006	Washer	8
67		3RA004	Washer	4